

OKA

Fabric Upholstered Furniture

Information and care guide
Please read and retain for future reference

FABRIC UPHOLSTERED FURNITURE

OKA's hand-crafted furniture is made with great care, using thoughtfully selected materials. With the correct care and maintenance, OKA furniture will provide years of comfort. Please familiarize yourself with the following information to ensure your complete satisfaction.

FABRIC FEATURES

- Delicate fabrics such as velvets have a raised pile and exhibit shading variations, crushing lines and bruising, which create unique features.
- Pile may compress over time in high use areas.
- Extra care with liquids should also be taken as these may leave marks.
- Fabrics with a linen and/or cotton content can pill and have fine threads visible. Some may have an uneven thickness in the fabric and may include occasional seeds and husks.
- Linen has a natural tendency to crease which enhances its textural appearance; creases will soften as the fabric relaxes in use. Pilling can occasionally occur in early stages of use, which is a feature of such fabrics.
- Due to the methods of dyeing used with certain fabrics there may be variations in color and shading, which can occur within the same dye lot.
- Every effort is made to ensure the products supplied correspond as closely as possible to display items in our showrooms and images used in our catalogues and on our website. However, due to unique characteristics of natural materials, variations may occur.

SLIP COVERS

- These create a more casual fit than fixed covers and offer versatility for cleaning and updating your look.
- Slip covers have an allowance for up to 3% shrinkage (which will vary from fabric to fabric) when cleaned and may not fit tightly on arrival.
- Slip covers are supplied separately to the frame and will require assembly upon arrival. Some of the slip covers may be slightly creased, but the creases will drop out naturally with time and use.

SEAT CUSHIONS, FILLINGS & SEAT COVERS

The appearance and performance of your cushions can be preserved by regular maintenance. Follow these simple steps as soon as your furniture arrives:

Foam with Fiber Wrap

- This is a firmer and more supportive filling than fiber which softens with use.
- Due to small tolerances in the polyurethane foam manufacturing process, hardness of foam may vary from cushion to cushion within the same product or order; the variance may reduce with use over time.
- Plump pillows firmly on the outside borders occasionally to restore air between the fibers and maintain the shape.
- Seat covers should be attended to and rotated regularly to realign the seat edges.

Fiber or Feather

- These soft and comfortable fillings require frequent maintenance.
- On occasion, fluff cushions firmly on the outside borders to restore air between the fiber or feather; this will maintain the look and comfort and help prevent the filling binding or flattening.

Complete the following maintenance routine at least once a week; the more often this is carried out, the better the filling will perform.

1. Place the cushion on one of its outside edges and beat the opposite border of the cushion inwards with the flat of your hands. The more vigorously you do this, the better.
2. Turn the cushion round a quarter turn onto the next side and repeat until all four sides have been beaten.
3. Finally, give the cushion a shake and replace.
4. Occasionally remove the filling interiors from their covers to plump them.

All Pillow Fillings

- Fillings which are not maintained correctly from the beginning will bind and become difficult to restore, losing comfort and shape.
- Swap reversible pillows around and turn where possible to ensure equal wear.
- Selected upholstery ranges have pillow covers which are not fully reversible. Non-reversible fiber-filled pillows should have the pad removed from the cover and turned over occasionally.
- Pillows are likely to have moved during transit and, as they need time to settle, this may cause slight lifting of the back pads. Rotation may be required so they sit correctly: ensure the pillow pads are positioned well back, squarely and flat on the seating platform so backs sit flat to the seat.
- The feel of the seat will vary depending on the fabric and size chosen; fabric compositions differ from fabric to fabric, which can give a more relaxed or firm feel to the seat when in use. Larger versions of a range have more pillow surface area for air to escape, so may compact more and feel different to smaller options in the same range.

LEGS, FEET & LEVELING

- Furniture must be positioned on a level solid surface to ensure the product does not rock, which can cause damage to the frame; use felt pads on feet if the floor is not level. Protect wooden and delicate flooring from possible marking by feet or castors by using felt pads or castor cups.
- Removable legs which screw in may loosen with use. Check monthly that they are secure by gently turning; be careful not to over tighten.
- Avoid dragging or dropping your upholstered furniture onto its corners or feet, or leaning back on two legs, as this may cause damage. Ensure you have two people to lift it and always place down gently.

CORNER UNITS

- Protect connecting brackets by maintaining stability, especially on hard slippery surfaces.

BED SKIRTS

- Any creasing or wrinkles caused by packaging will drop out after a short period of time.

FIRE RETARDANCY

- All foam is manufactured to meet stringent flammability regulations. Any additives used to comply with this standard may occasionally have a slight odor which will dissipate over time.

SUNLIGHT AND ENVIRONMENT

- If upholstery is exposed to direct sunlight for long periods of time, it will cause the color and fabric to deteriorate or discolor. Use in hot and sunny rooms is not recommended.
- At least a 12in clearance from heat sources, such as radiators, is advised to prevent color change or permanent marks occurring.
- Do not place hot items such as cups, laptops or hot water bottles on the fabric as this may leave a mark.
- We do not recommend placing products in excessively high or low temperatures, or where the environment is often damp, as this may cause product issues.

GENERAL MAINTENANCE INSTRUCTIONS

To help prolong the life of your upholstery, we advise the following:

Cleaning

- Regular cleaning with a soft brush and/or gently vacuuming helps keep your furniture looking its best. Accumulated dust will accelerate the wear of covers.
- Periodic cleaning of the entire piece is essential to maintain appearance and prevent premature fading and wear.
- All upholstery products should be professionally cleaned unless otherwise stated. We recommend using a reputable upholstery care professional. Requesting that a color test is performed and is satisfactory on an inconspicuous area before cleaning is recommended as OKA cannot take responsibility for third party damage or discoloration.
- Do not dry clean or wash covers unless it is specifically stated that you can, as doing so could result in a loss of fire-retardant properties and cause fabric durability issues.
- Remove all spills immediately. Blot liquid spills with a clean, dry, white cloth; work towards the center of the spill. Do not rub or use abrasive cleaners as this may damage the furniture. Should the piece become stained or suffer other damage, we recommend seeking professional advice or help.
- For wooden components, use a lightly damp cloth rinsed in warm water, do not use a detergent. Polish periodically with a natural wax.

Care

- Avoid sitting on the arms or edges of the furniture as this may cause distortion. Pushing feet against or placing on the piece may cause damage to the arm or frame.
- Using a footstool as a seat may cause damage to the legs and frame.
- Please do not allow your furniture to be jumped on as this will damage the springs and frame.
- Take care to prevent sharp objects such as toys, buckles, garment studs and heels from coming into contact with your furniture as they may cause damage. We recommend you discourage domestic pets from climbing on or clawing upholstery. If snags do occur do not pull them; instead, thread back in gently.
- Avoid air pollution such as cigarette smoke and cooking fumes, which can cause fabric to fade or change color.
- Avoid contact with chemicals such as household and baby wipes, hair and skin products, insect repellents and other cosmetics, and household cleaning materials other than those recommended, as these are likely to damage the surface.
- Take great care when unzipping covers and replace them correctly. Never force a zip and avoid trapping fabric when fitting or lifting items by the zips.

telephone: 1-800-621-8309
email: customercare@oka.com
oka.com/en-us/